


UPS Pico

Uninterruptible **P**ower **S**upply
with **P**eripherals and **I**²**C** control Interface

for use with

Raspberry Pi® Pi2, B+, A+, B, and A



HAT Compliant

"Raspberry Pi" is a trademark of the Raspberry Pi® Foundation

Short User Guide

Preliminary Version 1.4

© PiModules & ModMyPi

Intelligent Modules for your Raspberry Pi®

Designed and Manufactured by PiModules and ModMyPi

www.pimodules.com

www.modmypi.com

Document Revisions

Version	Date	Modified Pages	Modified Sections	Comments
1.0	28/01/2015	none	none	First Public Document Release
1.1	28/02/2015	21, 17	Figure 8, Figure 7	Updated new variables
1.2	24/03/2015	21 22	Figure 3, Figure 8	Updated BAT LED flashing time, according to firmware changes Updated FAN commands
1.3	14/04/2015	21 22	Figure 3, Figure 8	Commands updated
1.4	20/05/2015	16	Figure 1 0x6A	Change I2C address
1.4	20/05/2015	17	Figure 7 0x69	Change I2C address
1.4	20/05/2015	18	Figure 2 0x6B	Added more commands to the version Variable related to I2C setup

Document Revisions.....	2
Credits.....	5
System Overview	6
Introduction.....	6
Applications	7
Features.....	7
General Information	8
Mounting UPS Pico on Raspberry Pi®	8
UPS Pico Jumpers.....	9
UPS Pico Buttons	9
UPS Pico LEDs	11
UPS Pico I/Os.....	12
UPS Pico Advanced User Applications.....	12
Setting-up the I2C interface and RTC.....	13
The PICO (I²C) Interface - Peripherals I²C Control Interface	15
0x69 -> UPS Pico RTC Registers Direct Access Specification	16
Accessing 0x69 Varibales.....	16
0x6A ->UPS Pico Module Status Registers Specification	17
Accessing 0x6A Varibales	18
0x6B -> UPS Pico Module Commands	18
Accessing 0x6B Varibales.....	24
Setting Up the RaspberryPi® Serial Port for other applications	24
UPS Pico Terminal Commands Control (@commands RS232 interface)	27

Table of Figures

Figure 1 UPS Plco Jumpers Usage Table.....	9
Figure 2 UPS Plco Buttons Usage Table.....	10
Figure 3 UPS Plco LEDs Usage Table.....	11
Figure 4 I2C UPS Plco Interface and Simulated DS1307 Clock detection.....	14
Figure 5 UPS Plco Simulated DS1307 Clock sudo bash commands execution	14
Figure 6 0x69 -> UPS Plco RTC Registers Direct Access Table	16
Figure 7 0x6A -> UPS Plco Module Status Registers Specification	17
Figure 8 0x6B -> UPS Plco Module Commands	24
Figure 9 UPS Plco Jumpers	26
Figure 10 Minicom screenshot while the UPS Plco restarts.....	26
Figure 11 TCC @commands set.....	28

Credits

System Overview

Introduction

The **UPS Pico** is an advanced uninterruptible power supply for the Raspberry Pi® that adds a wealth of innovative power back-up functionality and development features to the innovative microcomputer!

The standard **UPS Pico** is equipped with a 300mAh LiPO battery specially designed to enable safe shutdown during a power cut. Additionally, this can be easily upgraded to the extended 3000mAh version, which enables prolonged use of a Raspberry Pi for **up to 8 hours** without a power supply connected!

The **UPS Pico** features an embedded measurement system that continuously checks the powering voltage of the Raspberry Pi®. When the cable power on the Raspberry Pi® is absent, insufficient, or the device detects a power failure, the **UPS Pico** automatically switches to the unit's battery source. The module then continues to check the voltage on the Pi and switches automatically back to the regular cable supply when power becomes once again available.

The **UPS Pico** is powered and the battery pack intelligently charged via the GPIO pins on the Raspberry Pi®, so no additional cabling or power supply is required.

The **UPS Pico** is designed to be 100% compliant with [HAT standards](#) for the Raspberry Pi® B+ and A+, and is mechanically compatible with the original Raspberry Pi® models A and B when an extension header is used. In addition to this, because the **UPS Pico** requires no external powering and fits within the footprint of the Raspberry Pi®, it is compatible with most cases.

The **UPS Pico** can also be equipped with an optional **Infra-Red Receiver** which is routed directly to GPIO18 via the PCB. This opens the door for remote operation of the Raspberry Pi® and **UPS Pico**!

Finally, the **UPS Pico** features an implemented Automatic Temperature Control **PWM fan controller**, and can be equipped with a micro fan kit, which enables the use of the Raspberry Pi® in extreme conditions including very high temperature environments.

Applications

UPS Pico is equipped with plenty of features which make it an extremely useful tool for Raspberry Pi® project development. It not only provides powering continuity, but also offers extra user programmable LEDs, sensors, buttons and I/O's. The unit also features a dedicated **10-bit analogue to digital converter** with two channels making it the perfect board for remote and unmanned sensor deployment. These extra features result in the **UPS Pico** being a superior all-in-one device, perfect for many innovative projects and embedded applications.

Features

The list of features of the **UPS Pico** is as follows:

- **Raspberry Pi B+ HAT Compliant**
- **Plug and Play**
- **Smart Uninterruptible Power Supply (UPS)**
- **Integrated LiPO Battery** (8-10 Minutes of Power Back-Up)
- **Intelligent Automatic Charger**
- **No Additional External Power Required**
- **Optional 3000 mAh Battery** for 8 Hours Run-Time (Not Included)
- **5V 2A Power Backup (Peak Output 5V 3A)**
- **Integrated Software Simulated Real Time Clock (RTC)** with Battery Back-Up
- **File Safe Shutdown** Functionality
- **Raspberry Pi B+ Activity Pin**
- **PWM fan control** (Fan Not Included)
- **2 User Defined LEDs**
- **2 User Defined Buttons**
- **Integrated Buzzer** for UPS and User Applications
- **Status Monitoring** - Powering Voltage, UPS Battery Voltage and Temperature
- **I²C PICO Interface** for Control and Monitoring
- **RS232 Raspberry Pi** Interface for Control and Monitoring
- **XTEA Based** Cryptography User Software Protection
- **2 Level Watch-dog Functionality** with **FSSD and Hardware Reset**
- **Raspberry Pi B+ Hardware Reset Button via Spring Test Pin** (Not Included)
- **Jumpers for Raspberry Pi B+ Pin** Functionality Selection
- **Stackable Header** for Add-On Boards
- **Boot Loader** for Live Firmware Update
- **Compatible with Intelligent IR Remote Power ON/OFF (PowerMyPi)**
- **Integrated ESD-Protected 2 Channel A/D 10 Bit Converters 0-5.2V**
- **Integrated ESD-Protected 1-Wire Interface**
- **Labeled J8 Raspberry Pi B+ GPIO Pins** for Easy Plug & Play
- **Infra Red Receiver** Sensor Interface (IR Not Included)
- **Upgradable with Pico Add-on Boards**
- **Fits Inside Most Existing Cases**

General Information

The **UPS Pico** Module uses the **5 VDC** and **GND** pins for powering, and interacts with the Raspberry Pi® through **GPIO_GEN22** and **GPIO_GEN27**. Simple Python script must be running on the Raspberry Pi® that interacts with the **UPS Pico** Module. The **GPIO_GEN22** is used to force the File Safe Shutdown (FFSD) procedure when the **UPS Pico** Module make it low, and read by the Raspberry Pi®. The **GPIO_GEN27** is used by the same Python script and generate a pulse train that is recognized by the **UPS Pico** Module and interpreted if the Raspberry Pi® is running or not. This approach allows simplifying the design, and cutting the needs to have current measure system on the **UPS Pico** Module. If the Raspberry Pi® is running (so the pulse train is generated) user can see that the UPS LED on the **UPS Pico** Module is flashing (fast if cable powered, and slow if battery powered). If the UPS LED is not flashing, it means that the Raspberry Pi® is not running (the Python script is not running). Therefore it is mandatory for a proper use of the **UPS Pico** Module to have the Python script installed. Due to this implemented feature, the UPS LED flashing functionality, user can by a single view have a knowledge if the Raspberry Pi® is running or not (Hang-up, or Shutdown).

It is important to notice that for the proper UPS Pico Module operation it is mandatory to have connected GPIO_GEN27 to the UPS Pico Module trough the FSSDU Jumper, as also installed the picofssd.py script. The GPIO_GEN27 is generating pulse train, that is interpreted by the UPS Pico Module and allows it to recognize different states of Raspberry Pi® powering conditions.

Mounting UPS Pico on Raspberry Pi®

In order to set up the **UPS Pico** Module some simple hand work is needed. Please follows the below steps before you start working with it.

1. If needed solder one or both of 3-pins connectors to the I/O
2. Check if all **green** jumpers are on their places,
3. Remove and save the **yellow** jumper for future HAT EEPROM programming, this procedure will be provided on www.pimodules.com
4. Put the **UPS Pico** Module on the top of the Raspberry Pi® without connected LiPO battery and cable power to the Raspberry Pi®
5. Connect the LiPO battery to the **UPS Pico** Module
6. Enter cable powering to the Raspberry Pi®

7. Press the UPSR button in order to set the start up conditions
8. If needed make factory defaults (described later on the following chapters)
9. Wait until the Raspberry Pi® boot up, and then verify the Green UPS LED blinking every 500 ms

It is important to be sure that when plugging the **UPS Pico Module** to the Raspberry Pi® the is not cable power connected to it as also LiPO battery connected to the **UPS Pico Module**.

UPS Pico Jumpers

For the Basic operation, **UPS Pico Module** uses only the **5 VDC** and **GND** pins and interacts with the Raspberry Pi® through GPIO_GEN22 and GPIO_GEN27. Some specialized features require in addition RS232 and I²C. In addition if the 1-wire device and IR Receiver are used, there are directly routed to GPIO_GEN04 and GPIO_GEN18 pins respectively. However these pins if not used with above features (the 1-wire not connected and IR Receiver not soldered) can be freely used as a standard GPIO pins. The RS232, GPIO_GEN22, GPIO_GEN27 and HAT EEPROM are going to the **UPS Pico Module** trough Jumpers set. Therefore, if user not needs some of them can remove the jumpers and free that pins for other applications.

Jumper	Description	Usage	Connection
RXD0	RS232 Receive	RX for RS232 @command for the UPS Pico	GPIO_GEN15
TXD0	RS232 Transmit	TX for RS232 @command for the UPS Pico	GPIO_GEN14
FSSDR	FSSD Raspberry Pi	File Safe Shutdown Pin for the Raspberry Pi	GPIO_GEN22
FSSDU	FSSD UPS Pico	RUN Pin for the UPS Pico	GPIO_GEN27
HATWP	HAT EEPROM WP	HAT EEPROM Write Protection	EEPROM WP

Figure 3 UPS Pico Jumpers Usage Table

UPS Pico Buttons

The **UPS Pico Module** is equipped with 5 buttons that can be used in various ways. Two of them are dedicated for user applications and can be handled by user through the **PiCo** (I²C) interface or **@commands** (RS232), all other are specific for various **UPS Pico Module** functionalities. All of them can be used for some start-up functionalities when **UPS Pico Module** is reset. A detailed description of all buttons and their usage is provided on below table.

Button	Description	Usage	Additional Functionalities
RPiR	Raspberry Pi Hardware Reset	<p>Make Raspberry Pi Hardware Reset when pressed. To be used need installed (soldered) the Gold Plated Reset Pin.</p> <p>NOTE1: Resetting of the Raspberry Pi®, can corrupt files on the SD card if used</p> <p>NOTE2: Resetting of the Raspberry Pi®, does not affect the UPS Pico (including Pico RTC)</p>	NONE
UPSR	UPS Pico Hardware Reset	<p>Make UPS Pico Hardware Reset when pressed.</p> <p>NOTE1: Resetting of the UPS Pico does not reset the Raspberry Pi®.</p> <p>NOTE2: Resetting of the UPS Pico does reset the simulated RTC to default values.</p>	When pressed with combination with other buttons activate various start-up functionalities. The procedure is to press first the UPSR button, and then another one, then release the UPSR button and then release the other button (valid for FSSD , KEYA , KEYB).
FSSD	File Safe Shutdown	When pressed initiate the File Safe Shutdown Procedure. If used need to have FSSDR Jumper short. If Raspberry Pi®+UPS Pico system battery powered, after FSSD finished UPS Pico will cut the power. Pressed again (need to have installed the Gold Plated Reset Pin for the restart option), start the Raspberry Pi®+UPS Pico system again.	When used with UPSR button, make factory self test, used during boards testing. Not useful for user, as a special test board with spring test pins need to be connected.
KEYA	User Key A	Can be used for User Application – Read the status via Pico (I ² C) or RS232 interface	When used with UPSR button, makes the factory default, and reset the RTC to startup values.
KEYB	User Key B	Can be used for User Application – Read the status via Pico (I ² C) or RS232 interface	When used with UPSR button, invokes the bootloader (light the Red User LED). The bootloader can be invoked also from the Pico interface.

Figure 4 UPS Pico Buttons Usage Table

UPS Pico LEDs

The **UPS Pico** Module is equipped with 6 LEDs that offers information about the **UPS Pico** Module system status. Two of them are dedicated for user applications and can be handled by the **PiCo** (I²C) interface or **@commands** (RS232). One of them is **Red** and the second one is **Blue**. A detailed description of all LEDs and their usage is provided on below table.

LED	Description	Usage
UPS LED - Green	Provide information about UPS Pico Module status	<ul style="list-style-type: none"> Flashes Normally when system is cable powered and Raspberry Pi® is running (100 ms ON, 500ms OFF) Flashes Slow when system is battery powered and Raspberry Pi® is running (100ms ON, 2000ms OFF) Flashes Fast when FSSD is executed (100ms ON, 200ms OFF) Not light when UPS Pico Module is in Low Powering Mode (LPR) and the Raspberry Pi® is not running.
BAT LED - Orange	Provide information about UPS Pico Module Battery Level when system is powered from it or continuously lit when Pico system error occurs. See description " Figure 8 0x6B -> UPS Pico Module Commands "	<ul style="list-style-type: none"> Battery Level > 3.7 V BAT LED not Flash 3.7V <= Battery Level > 3.5 V BAT LED Flashes 100ms ON, 2000ms OFF 3.4V <= Battery Level > 3.5 V BAT LED Flashes 100ms ON, 500ms OFF 3.3V <= Battery Level > 3.4 V BAT LED Flashes 100ms ON, 200ms OFF FSSD is immediately initiated <p>When Pico registers data written to the internal EEPROM LED Lights for 1 second</p>
CHG LED - Green	Provide information about UPS Pico Module Battery Charger Status	It is valid only when cable powering is present. When battery is charged the CHG LED Lights.
HOT LED - Orange	Provide information about UPS Pico Module Temperature. Read both sensors (the embedded SOT23 and the Pico FAN Kit TO092) and shows the higher one.	When system temperature is higher than threshold the HOT LED lights. The temperature is measured on both sensors the SMD placed on the top as also on the TO-92 is Pico FAN Kit is used. The higher temperature on one of them activates the HOT LED, and remains until both sensors have lower temperature than the threshold. The default value is 42 Degs Celsius.
LED RED - PLCC2 size	Provided for UPS Pico Module User Application	Available for user application. Handled by the PiCo and @commands interface. During Boot Functionalities support interaction with various lightings
LED BLUE - PLCC2 size	Provided for UPS Pico Module User Application	Available for user application. Handled by the PiCo and @commands interface. During Boot Functionalities support interaction with various lightings

Figure 5 UPS Pico LEDs Usage Table

UPS Pico I/Os

The **UPS Pico** Module is equipped with 4 I/Os, there are:

- 1-wire interface
- 10 bits A/D converter 1 (0 - 5.2V)
- 10 bits A/D converter 2 (0 - 5.2V)
- IR Receiver

The 1-wire interface is supported with supply of 3.3V (which is independent from the Raspberry Pi® powering) and GND on the same connector. It simplifies the connection making when the 1-wire is used. In addition the 1-wire interface is ESD protected. Is is directly routed to the GPIO_GEN04. If the 1-wire sensor is not used the GPIO can be used for any other application on the J8 pins. It contains just the required 4K7 resistor connected to the 3.3V.

The UPS Pico Module supports also pre-calibrated 2 x 10 bits A/D converters. Their readings can be easy accessed easy via **PICo** (I²C) interface or **@commands** (RS232). Read values are in mV. Those inputs are also ESD protected.

The IR Receiver if assembled (soldered on the PCB) is directly routed to the GPIO_GEN18. A very good tutorial how to use it can be found on below link:

<https://www.modmypi.com/blog/raspberry-pis-remotes-ir-receivers>

User does not need to add any other component in order to use the IR Receiver. If the IR Receiver is not used (not soldered to the PCB) the GPIO_GEN18 can be used for any other application.

UPS Pico Advanced User Applications

The **UPS Pico** Module uses the **5 VDC** and **GND** pins for powering, and interacts with the Raspberry Pi® through GPIO_GEN22 and GPIO_GEN27. Simple Python script is mandatory to be running on the Raspberry Pi® that interacts with the **UPS Pico** Module. After installing of that Python script there is no real need for any additional tasks to use the UPS Pico Modules.

However, there is a group of users that have more advanced needs. In order to cover them 2 different interfaces have been implemented:

- The **Peripherals I²C Control** (PICo) Interface, based on the I²C, and
- The **Terminal Commands Control** (TCC) Interface, based on the RS232

Both of them are independent and can be used separately. In order to use both of them, a some additional installation works is needed.

In order to use I²C and RTC (that is communicating with OS via I²C), a simple I²C set up is needed.

Setting-up the I2C interface and RTC

The I²C Ports on the Raspberry Pi® are not enabled by default. Follow these steps to enable the I²C ports and the RTC communicate with RaspberryPi® through I²C.

First of all, the config file must be edited that by default disables the I²C port. This setting is stored in `/etc/modprobe.d/raspi-blacklist.conf`.

```
sudo nano /etc/modprobe.d/raspi-blacklist.conf
```

Once this file is open, find the line **blacklist i2c-bcm2708** and comment it out by adding a hash character (#) in front of it as shown here below, then save and close the file.

```
#blacklist i2c-bcm2708
```

Now edit `/etc/modules`:

```
sudo nano /etc/modules
```

and add the following lines, then save and close the file.

```
i2c-bcm2708  
i2c-dev  
rtc-ds1307
```

Reboot the system:

```
sudo reboot
```

Install I²C tools by running the following command (assuming that you're connected to Internet)

```
sudo apt-get install i2c-tools
```

Now look for ID #68 with `i2cdetect`. Depending on the model of your Raspberry Pi, this must be done in two different ways:


- On a 256MB Raspberry Pi Model A+:

```
sudo i2cdetect -y 0
```

- On a 512MB Raspberry Pi Model B+:

```
sudo i2cdetect -y 1
```

The result should look like the following:



```

pi@raspberrypi: ~
pi@192.168.1.6's password:
Linux raspberrypi 3.12.28+ #709 PREEMPT Mon Sep 8 15:28:00 BST 2014 armv6l

The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
Last login: Sat Jan 10 17:06:49 2015 from turbopc.lan

pi@raspberrypi ~ $
pi@raspberrypi ~ $
pi@raspberrypi ~ $ sudo i2cdetect -y 1
    0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
10:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
20:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
30:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
40:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
50:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
60:  --  --  --  --  --  --  --  --  68 69 6a 6b  --  --  --
70:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
pi@raspberrypi ~ $

```

Figure 6 I2C UPS Pico Interface and Simulated DS1307 Clock detection

Then, running as root, do the following (also depending on the model)

- On a 256MB Raspberry Pi Model A+:

```

sudo bash
echo ds1307 0x68 > /sys/class/i2c-adapter/i2c-0/new_device
exit

```


- On a 512MB Raspberry Pi Model B+:

```

sudo bash
echo ds1307 0x68 > /sys/class/i2c-adapter/i2c-1/new_device
exit

```

The result should look like:



```

pi@raspberrypi ~ $ sudo bash
root@raspberrypi:/home/pi# echo ds1307 0x68 > /sys/class/i2c-adapter/i2c-1/new_device
root@raspberrypi:/home/pi# exit
exit
pi@raspberrypi ~ $

```

Figure 7 UPS Pico Simulated DS1307 Clock sudo bash commands execution

Then check for time from the clock (which will show Sat 01 Jan 2000 if it is the first time that it is used):

```
sudo hwclock -r
```

Then write the current system time to the clock:

```
sudo hwclock -w
```

Finally edit the /etc/rc.local file:

```
sudo nano /etc/rc.local
```

and just before the line that reads **exit 0**, add the following two lines, then save and close the file:

- On a 256MB Raspberry Pi Model A+:

```
echo ds1307 0x68 > /sys/class/i2c-adapter/i2c-0/new_device  
hwclock -s
```

- On a 512MB Raspberry Pi Model B+:

```
echo ds1307 0x68 > /sys/class/i2c-adapter/i2c-1/new_device  
hwclock -s
```

The PICO (I²C) Interface - Peripherals I²C Control Interface

The **Peripherals I²C Control** – The **PICO Interface** – is an implementation of **I²C** interface adapted to easy control of the peripheral connected to the Raspberry Pi® via command line. By using human understandable simple commands, control of peripherals is made extremely simple. Control at programming language level is also possible and easy. The core concept of the **PICO interface** is that all peripheral device control and data exchange between it and Raspberry Pi® variables are common for the **I²C interface** as also for the peripheral itself. Therefore any change of them by either party, Raspberry Pi® and the peripheral, causes immediate update and action.

Two types of variables are available:

- **Common**, where data are stored in the same place and any change on it will cause action on the **UPS Pico Module**
- **Mirror**, where are copy of data stored on internal variables of the **UPS Pico Module**, they are protected, so changes on it will not implies the **UPS Pico Module** functionality and will be overwritten immediately when **UPS Pico Module** recognized changes on them

There have been implemented 3 **PICO** addresses assigned to the following entities:

0x6A -> UPS Pico RTC Registers Direct Access Specification

Address	Name	Size	Type	R/W	Explanation
0 or 0x00	Seconds	Byte	Mirror	Read	Seconds in BCD
1 or 0x01	Minutes	Byte	Mirror	Read	Minutes in BCD
2 or 0x02	Hours	Byte	Mirror	Read	Hours in BCD
3 or 0x03	DOW	Byte	Mirror	Read	DOW in BCD
4 or 0x04	Days	Byte	Mirror	Read	Days in BCD
5 or 0x05	Month	Byte	Mirror	Read	Month in BCD
6 or 0x06	Year	Byte	Mirror	Read	Year in BCD
7 or 0x07	RTCCF	Byte	Common	R/W	<p>Real Time Clock Correction Factor in HEX</p> <p>Change the RTC timer for multiples of 1 tick per second Timers tick is 1/32768 Hz= 0,000030517578125 sec</p> <p>Write: 0x00 or 0x80 not change the RTC tick</p> <p>Write: 0x01 – 0x79 change the RTC tick by subtract tick multiplication from the standard timer values, therefore it will decrease the “duration” of each second by multiple value of timer ticks – counted second will be shorter, so RTC will be running faster</p> <p>Write: 0x81 – 0xFF change the RTC tick by adding tick multiplication to the standard timer values, therefore it will increase the “duration” of each second by multiple value of timer ticks – counted second will be longer, so RTC will be running slower</p> <p>Adding or subtract of one tick change the 24 hours RTC by 86400 * 0,000030517578125 sec = 2,63671875 seconds</p> <p>Read: Checks actual RTCCF Value</p>

Figure 8 0x6A -> UPS Pico RTC Registers Direct Access Table

Access to these variables can be done indepened if the RTC is used by the Raspberry Pi(R) system. The last variable is **Common** changes of it trim the RTC accuracy according to specifications provided in above table. Therefore writting to this register cause immediate action and trimming of the RTC.

Accessing 0x69 Varibales

In order to access the **0x6A** variavbles the following commands need to be executed form the OS command line

```
sudo i2cget -y 1 0x6A 0
```

The result will be the seconds register value of the implemented RTC. There are a very good python script and “C” software that showing how to access them, on our products forum.

```
sudo i2cget -y 1 0x6A 1
```


The result will be the minutes counter of the implemented RTC.

```
sudo i2cset -y 1 0x6A 7 0x01
```

The result will set the RTCCF trimming RTC factor to 1.

0x69 -> UPS Pico Module Status Registers Specification

Address	Name	Size	Type	R/W	Explanation
0 or 0x00	mode	Byte	Mirror	Read	Powering Mode – Read ONLY, Writing has no effect on the system and will be overwritten by UPS Pico with the new value 0x01 - RPI_MODE 0x02 - BAT_MODE
1 or 0x01	batlevel	Word	Mirror	Read	Means value of Battery Voltage in 10 th of mV in BCD format
3 or 0x03	rpilevel	Word	Mirror	Read	Means value of Voltage supplying RPi on J8 5V Pin in 10 th of mV in BCD format
5 or 0x05	AD1Vlevel	Word	Mirror	Read	Means value of Voltage supplying USB on P1 5V Pin in 10 th of mV in BCD format
7 or 0x07	AD2Vlevel	Word	Mirror	Read	Means value of Voltage supplying EPR on P1 5V Pin in 10 th of mV in BCD format
9 or 0x09	KEYA	Byte	Mirror	R/W	Contain 0x01 if KEYA is pressed, and remain until will write back with 0x00. User need to write 0x00 always after reading it. Non pressed KEYA is 0x00, pressed KEYA is 0x01
10 or 0x0A	KEYB	Byte	Mirror	R/W	Contain 0x01 if KEYB is pressed, and remain until will write back with 0x00. User need to write 0x00 always after reading it. Non pressed KEYB is 0x00, pressed KEYB is 0x01
11 or 0x0B	KEYF	Byte	Mirror	R/W	Contain 0x01 if KEYF is pressed, and remain until will write back with 0x00. User need to write 0x00 always after reading it. Non pressed KEYF is 0x00, pressed KEYF is 0x01
12 or 0x0C	tmpcels	Byte	Mirror	R/W	Temperature in Celcius degree of the SOT-23 sensor placed on the top of PCB. Values in BCD format.
13 or 0x0D	tmpcelt	Byte	Mirror	R/W	Temperature in Celcius degree of the TO-92 sensor placed on the bottom of PCB. It is valid only if this sensor is soldered. It is available in the Pico Fan Kit. Values in BCD format.

Figure 9 0x69 -> UPS Pico Module Status Registers Specification

Access to those variables offers information about **UPS Pico** Modules status and their peripherals. All of them are *mirror* so are available for reading. However the KEYA, KEYB and KEYF need to be “reseted” (by writting 0x00) after reading in order to prepare them for the next key pressed status.

Accessing 0x69 Variables

In order to access the **0x69** variables the following commands need to be executed from the OS command line

```
sudo i2cget -y 1 0x69 0
```

The result will be the powering mode

```
sudo i2cget -y 1 0x69 5 w
```

The result will be the AD1 value in 10th of milivolts

```
sudo i2cget -y 1 0x69 9
```

The result will be the status of the KEYA and if pressed will be 0x01, if not 0x00. In case that the result is 0x01 (key pressed) this variable needs to be reset by writing 0x00.

```
sudo i2cset -y 1 0x69 9 0x00
```

0x6B -> UPS Pico Module Commands

Address	Name	Size	Type	R/W	Explanation
0 or 0x00	version	Byte	Common	R/W	<p>Version.Factory.Reset.FSSD. Bootloader.I2C</p> <p>Read: Check the actual firmware Version</p> <p>Write: 0xa0 – Set the I2C Addresses Registers to I2C_NORMAL where the following addresses are used: 68 69 6a 6b – defined for all functions of UPS Pico 6c 6d 6e 6f – defined for functions related to Event Driven Time Based ON/OFF Scheduler of UPS Pico and will be defined in next version of firmware sudo i2cset -y 1 0x6b 0 0xa0</p> <p>Write: 0xa1 – Set the I2C Addresses Registers to I2C_MINIMAL where the following addresses are used: 68 69 6a 6b – defined for all functions of UPS Pico sudo i2cset -y 1 0x6b 0 0xa1</p> <p>Write: 0xa2 – Set the I2C Addresses Registers to I2C_NORTC where the following addresses are used: 6A 6b – defined for all functions of UPS Pico Releases the 0x68 and 0x6A of the internal RTC and give it for other additional RTC devices sudo i2cset -y 1 0x6b 0 0xa2</p> <p>Each change of the I2C configuration cause UPS Pico Restart.</p> <p>Default Value is 0xA1 - MINIMAL</p>

					<p>Write: 0xcc – Unconditional File Safe Shutdown and (and Power OFF when battery powered)</p> <p>Write: 0xdd - then restore factory defaults Will stay in the values of 0xdd until factory defaults restored, and then will be set to version of the firmware.</p> <p>Write: 0xee - Reset the UPS Plco CPU, it cause start-up values i.e. RTC will be set to 01/01/2000</p> <p>Write: 0xff - Call the UPS Plco Bootloader, RED Led will be light. Recover from this state can be done <u>only</u> by pressing the RST button or new firmware upload. All interrupts are disabled during this procedure. It should be used with RPi Uploading firmware script. Use it very carefully and only when is needed – when firmware uploading. Do not play with it; this is not a toy functionality. Powering of the pair UPS Plco+RPi must be done via RPi micro USB socket during boot loading process due to following UPS Plco Resets after firmware uploading or when returning from this mode. The UPS functionality as also all others is not working when entering this mode.</p> <p>Due to required protection for the RPi from the unconditional reset (files corruption), it is not possible to enter to this mode when system is powered in a different way than in RPi Powering Mode.</p>
1 or 0x01	error_code	Byte	Mirror	Read	<p>UPS Plco System Error Code</p> <p>Read: 0x00 – No error</p> <p>If UPS Plco System Error happens, then the BAT LED continously light until wrong conditions will be corrected</p> <p>Each Bit of this variable represent a specific error: Bit 0 – RPi Powering Voltage lower than 4.7V Bit 1 – Battery Voltage lower than 3.3V Bit 2 – Battery Temperature higher than 50 C Bit 3 – UPS Plco System watch-dog restart Bit 4 – TBS Bit 5 – TBS Bit 6 – TBS Bit 7 – ON when writting data to Plco EEPROM</p> <p>User action is required in order to cancel the System Error Code, by writting the 0x00 to this register. If System Error still exists will be overriten again with its code. UPSR clear this register value. No User action is required when when data are writting to the Plco EEPROM</p>
2 or 0x02	rpi_serror	Word	Mirror	Read	Means value of Voltage supplying RPi on J8 5V Pin in 10 th of mV in BCD format when UPS Plco System Error happen
4 or 0x04	bat_serror	Word	Mirror	Read	Means value of Battery Voltage in 10 th of mV in BCD format when UPS Plco System Error happen
6 or 0x06	tmp_serror	Word	Mirror	Read	Meana value of Battery Sensor Temperature in BCD

					format (Celcius Degrees) when UPS Plco System Error h appen
8 or 0x08	sta_counter	Byte	Common	R/W	<p>Still Alive Timeout Counter in seconds in HEX format</p> <p>Read: Anytime, Return actual sta_counter value</p> <p>Write: 0xff – Disable the counter (default value)</p> <p>Write: 0x01 – 0xfe Enable and start down counting of the Still Alive Time Counter in resolution of 1 second, until reaches value of 0x00 which initiate the File Safe Shutdown Procedure</p> <p>Write: 0x00 – Initiate immediately File Safe Shutdown Procedure and system restart with similar conditions as described below</p> <p>In order to use it as Still Alive (type of watchdog) timer, user needs to upload value from 0x01 to 0x0fe earlier than defined time of seconds. Not uploading of this value will cause System File Safe Shutdown after time out. The maximum time out is 254 second.</p> <ol style="list-style-type: none"> 1. When Cable Powering is connected and Gold Plated Reset Pin is installed, then first try is to execute FSSD, and after that hardware reset by setting LOW on the Raspberry Pi RUN pin for 250 ms is followed. If Gold Plated Reset Pin is not installed, the hardware reset will be not executed. That means the Raspberry Pi will not reset, if hangs up. So System will not restart again. 2. When Cable Powering is disconnected (system is powered via Plco battery) and Gold Plated Reset Pin is installed, then first will try is to execute FSSD, and after that hardware reset by setting LOW on the Raspberry Pi RUN pin for 250 ms is followed. If Gold Plated Reset Pin is not installed, the hardware reset will be not executed however the battery powering will be cutted for 250 ms. That means the Raspberry Pi will reset, if hangs up. So System will restart again. <p>After execution of the STA Restart the sta_counter is set again to 0xFF (disabled).</p>
9 or 0x09	fssd_batime	Byte	Common	R/W	<p>Battery Running Time when cable power loses. After that time a File Safe Shut Down Procedure will be executed and System will be shutdown without restart. Battery power will be diconected. System is in sleep mode (LPR) aqnd RTC is runing.</p> <p>If Raspberry Pi cable power returns again system will be start automaticly.</p> <p>If during the sleep mode (LPR) the FSSD button will be presed for longer time than 2 seconds (with</p>

					<p>battery or cable powering) Raspberry Pi will re-start again.</p> <p>Value of 0xff (255) disable this timer, and system will be running on battery powering until battery discharge to 3.5 V.</p> <p><u>Factory default value is 120 seconds</u></p> <p>Value higher than 15 seconds are only accepted</p> <p>Writing of smaller value than 15 seconds to this register, will be overwritten with 30 seconds (0x14)</p> <p>Read: Anytime, Return actual fssd_timeout value</p> <p>Write: 0x14 – UPiS will cut the power after FSSD (default value) – 30 seconds</p> <p>Must be bigger than 15 seconds (0x0F), if smaller is set, then automatically will be selected the default value</p> <p>Any change on this register will cause immediate writing of the new value to the Pico EEPROM</p>
10 or 0x0A	lprsta	Byte	Common	R/W	<p>Low Power Restart Time in seconds in HEX format (from 0x01 – 0xff)</p> <p>This is the timer which counts how often the power will be checked in Low Powering Mode in order to restart the system. Default value is 5 seconds. More often checking means faster response to power come back, however consumes more power from the battery. Less often means slower response to power come back, however consumes less power from battery.</p> <p>Default value is 5 seconds. This means that when cable power return, it will be recognized within maximum 5 seconds and switch ON the UPS Pico. The same timer is used also for the button presses restart RPi.</p> <p>The RPi+UPS Pico system will go to the Low Powering Mode (LPR) after the lprsta timer value.</p> <p>This is valid in all cable powering modes, except of the RPi mode.</p> <p>0x00 is not allowed and will be ignored by the system</p> <p>Write: 0x01 – 0xff set the time in seconds</p> <p>Read: Anytime, Return actual lprsta value</p> <p>Value of the lprsta will be stored in the UPS Pico EEPROM</p>
11 or 0x0B	btto	Byte	Common	R/W	<p>Battery Powering Testing Timeout</p> <p>This is timer that force the UPS Pico when battery powered to check if cable power returns. Default it is 5 seconds. So, when UPS Pico+RPi are powered</p>

					<p>from battery, every 5 seconds the UPS Pico checks if powering cable has been entered (the RED RPi LED flashes then), and if yes then switch off the battery, and after 2 seconds start up the battery charger, if not - continue battery powering.</p> <p>Read: Anytime, Return actual btto value</p> <p>Write: 0xff – Not allowed Write: 0x01 – Not allowed</p> <p>Write: 0x02 – 0xfe time in seconds</p>
12 or 0x0C	led_blue	Byte	Common	R/W	<p>LED BLUE - PLCC2 size ON - Write: 0x01 LED BLUE - PLCC2 size OFF - Write: 0x00</p>
13 or 0x0D	led_red	Byte	Common	R/W	<p>LED RED - PLCC2 size ON - Write: 0x01 LED RED - PLCC2 size OFF - Write: 0x00</p>
14 or 0x0E	bmode	Byte	Common	R/W	<p>Integrated Buzzer Mode</p> <p>Read: Anytime, Return actual bmode value</p> <p>Write: 0x00 – Unconditional Disable the buzzer</p> <p>Write: 0x01 – Unconditional Enable the buzzer</p> <p>Write: 0x02 – Enable Automatic buzzer functionality – beep only when is defined in the firmware</p> <p>UPS Pico restarts always with automatic Buzzer Mode</p>
15 or 0x0F	fmode	Byte	Common	R/W	<p>Integrated Fan Running Mode</p> <p>Read: Anytime, Return actual fmode value</p> <p>Write: 0x00 – Unconditional Disable the FAN with selected speed from the fspeed</p> <p>Write: 0x01 – Unconditional Enable the FAN with selected speed from the fspeed</p> <p>When UPS Pico is going down to the LPR mode, the FAN is automatically disabled, and enabled again when the UPS Pico returns to normal work</p>
16 or 0x10	fspeed	Byte	Common	R/W	<p>Integrated Fan Speed</p> <p>Read: Anytime, Return actual fspeed value</p> <p>Write: 0x00 – Selected speed when ON is 0% (not running)</p> <p>Write: 0x01 – Selected speed when ON is 100% (full speed running)</p> <p>Write: 0x02 – Selected speed when ON is 25%</p> <p>Write: 0x03 – Selected speed when ON is 50%</p> <p>Write: 0x04 – Selected speed when ON is 75%</p>
23 or 0x17	XBMC	Byte	Common	R/W	<p>Activate XBMC Mode Added XBMC functionality, running without python</p>

					<p>script needs, especially addressed for XBMC users. System is running normally when cable power connected and when cable power removed, system will stops (cut the battery power without FSSD) after specified time out (60 seconds). During this time the Raspberry Pi will shut down by itself forced by the Pulse-Eight CEC driver. Reconnecting the power (switch ON TV) starts again the Raspberry Pi. The XBMC functionality is also useful for any other application when user would like to have a full control of system shutdown without assigning any GPIO for that. On such applications (non XBMC) user will need to monitor the I2C Powering Mode Variable and when switch to battery shutdown within required time (60 seconds). Not needed for XBMC.</p> <p>During this mode all other triggers for the FSSD are not working. There are:</p> <ul style="list-style-type: none"> • Still Alive Timer • FSSD when button • Low Battery FSSD • Timed FSSD UPS when in battery mode <p>When power is cut from the Raspberry Pi, the UPS Plco is entering the LPR mode, and recover is done only when cable power is back. The RTC is running during that LPR mode. This functionality implements a perfect media player, when the Raspberry Pi is powered from a USB from the TV. Then when TV is OFF, the Pulse-Eight CEC driver safety shutdown the Raspberry Pi, and after that the UPS Plco cut the power. When TV is switched ON again, the media player starts again.</p> <p>Combining this mode with IR mounted give to the user a full remote controlled Media Player</p> <p>Default value is: 0x00 (OFF)</p> <p>Read: Anytime, Return actual XBMC value</p> <p>Write: 0x01 – Activate XBMC Mode Write: 0x00 – deActivate XBMC Mode</p>
24 or 0x18	FSSD_tout	Byte	Common	R/W	<p>Set the timeout needed for the FSSD procedure to be completed</p> <p>The FSSD timeout specify how long the FSSD procedure will takes long. The FSSD timeout cannot be smaller than 32 seconds.</p> <p>Default value is: 0x20 seconds (32 seconds)</p> <p>Read: Anytime, Return actual FSSD_tout value</p> <p>Write: 0x2d – 0xff – Set the FSSD_tout Write: 0x00 – 0x2d – not allowed, will be overwritten with default value</p>

--	--	--	--	--	--

Figure 10 0x6B -> UPS Plco Module Commands

Accessing 0x6B Variables

In order to access the **0x6B** variables the following commands need to be executed from the OS command line

```
sudo i2cset -y 1 0x6B 12 1
```

The result will be lighting the **LED BLUE - PLCC2 size ON**

```
sudo i2cset -y 1 0x6B 12 0
```

The result will be lighting the **LED BLUE - PLCC2 size OFF**

```
sudo i2cset -y 1 0x6B 13 1
```

The result will be lighting the **LED RED - PLCC2 size ON**

```
sudo i2cset -y 1 0x6B 13 0
```

The result will be lighting the **LED RED - PLCC2 size OFF**

```
sudo i2cget -y 1 0x6B 0
```

The result will be the current firmware version code i.e. 0x0F

Setting Up the RaspberryPi® Serial Port for other applications

By default Raspberry Pi®'s serial port is configured to be used for console input/output. While this is useful if you want to log in using the serial port, it means that you can't use the Serial Port in your programs. To be able to use the serial port to connect and talk to other devices, the serial port console logins need to be disabled.

Needless to say, if you do this then you need some other way to log in to the Raspberry Pi®; we suggest using an SSH connection over the network.

Disable Serial Port Login

To disable logins on the serial port, there are two files that need to be edited. The first and main one is /etc/inittab. You can edit it by issuing this command¹:

```
sudo nano /etc/inittab
```

¹ throughout this manual we will assume that text files are edited with nano and that the user knows how to save the file, after editing. However, instead of nano the user is free to use any other text editor that he or she feels comfortable with.

This file contains the command that enables the login prompt, that needs to be disabled. Move to the end of the file: you will see a line similar to:

```
T0:23:respawn:/sbin/getty -L ttyAMA0 115200 vt100
```

Disable it by adding a # character to the beginning, as shown here below, then save the file.

```
#T0:23:respawn:/sbin/getty -L ttyAMA0 115200 vt100
```

Disable Boot-up Info

When the Raspberry Pi® boots up, all the boot log information is sent to the serial port. Disabling this boot log information is optional and you may want to leave this enabled as it is sometimes useful to see what happens at boot and if you have a device connected (i.e. Arduino) at boot, you might want it to receive this information over the serial port, so it is up to you to decide whether to keep this boot logging enabled or disable it.

If you decide to disable it, you can do it by editing the file /boot/cmdline.txt:

```
sudo nano /boot/cmdline.txt
```

The content of the file looks like this

```
dwc_otg.lpm_enable=0 console=ttyAMA0,115200 kgdboc=ttyAMA0,115200 console=tty1  
root=/dev/mmcblk0p2 rootfstype=ext4 elevator=deadline rootwait
```

Remove all references to ttyAMA0 (which is the name of the serial port), then save the file and close it. The file will now look like this:

```
dwc_otg.lpm_enable=0 console=tty1 root=/dev/mmcblk0p2 rootfstype=ext4  
elevator=deadline rootwait
```

Reboot

In order to enable the changes you have made, you will need to reboot the Raspberry Pi:

```
sudo shutdown -r now
```

Test the Serial Port

A great way to test out the serial port is to use the **minicom** program. If you don't have this one installed and you are connected to Internet, then you can install it by running

```
sudo apt-get install minicom
```

Run up **minicom** on the Raspberry Pi® using

minicom -b 38400 -o -D /dev/ttyAMA0

Make sure that the jumpers required for serial connection (**RXD0** and **TXD0**) are installed and that no other boards using the serial port are placed on the top of the **UPS Pico**.



Figure 11 UPS Pico Jumpers

By pressing the **UPSR** (the UPS Reset Button) you should see on the **minicom** screen the **UPS Pico** welcome message after reset. This will ensure you that the **UPS Pico** is cooperating properly with your Raspberry Pi[®].




Figure 12 Minicom screenshot while the UPS Pico restarts

Be careful when pressing the **UPSR** (the UPS Reset Button) to avoid pressing also the **RPIR** (the Raspberry Pi[®] Reset Button), because that other button would force a reset of the Raspberry Pi[®] and cause the immediate cutting of communication between the **UPS Pico** and the Raspberry Pi[®].

NOTE1: Resetting of the **UPS Pico** does not reset the Raspberry Pi[®].

NOTE2: Resetting of the **UPS Pico** does reset the simulated RTC to default values.

NOTE3: Resetting of the Raspberry Pi[®] does not reset the **UPS Pico**, therefore the RTC keeps working and the time information is not lost.

NOTE4: Resetting of the Raspberry Pi® is possible only if the **Reset Gold Plated Pin** is installed (soldered).

UPS Pico Terminal Commands Control (@commands RS232 interface)

The **UPS Pico** Module uses the **5 VDC** and **GND** pins for powering, and interacts with the Raspberry Pi® through GPIO_GEN22 and GPIO_GEN27. Simple Python script must be running on the Raspberry Pi® that interacts with the **UPS Pico** Module. After installing of that Python script there is no need for any additional tasks to use the UPS Pico Modules. However, there is a group of users that have more advanced needs. The **Terminal Commands Control** was specifically addressed for them and is an alternative way for advanced controll of the **UPS Pico** Module other than PICO (I²C) Interface.

There are plenty of commands for full system control. Thanks to the implemented bootloader, the set of commands can be constantly enhanced with new ones, as we release more of them. We are open to customer suggestions about new commands to implement. Customers can propose new commands by e-mail or on our forum: if we find them generally useful, then we will implement them for free and distribute them via our bootloader system. Customized versions of the firmware featuring customer-specific commands are also possible.

Command	Meaning	Explanation - Usage	Action
@factory	Factory Defaults	@factory or @FACTORY	Return UPS Pico to Factory Default Values. Should be used always after upload of a new firmware. Executing of this command does not reset the Raspberry Pi, so can be used when powered from battery
@version	Firmware and Hardware Release Version	@version or @VERSION	Return UPS Pico Hardware and Firmware Version
@status	Status of the System	@status or @STATUS	Return UPS Pico system status
@ad1	Read First A/D converter	@ad1 or @AD1	Return the first A/D converter value in mili volts
@ad2	Read Second A/D converter	@ad2 or @AD2	Return the second A/D converter value in mili volts
@pm	Powering Mode	@pm or @PM	Return the Powering Mode
@bat	Value of the Battery Level	@bat or @BAT	Return the Battery Level value in mili volts
@rpi	Value of the J8 5V Level	@rpi or @RPI	Return the 5V on J6 connector Level value in mili volts
@time	Pico RTC Time	@time or @TIME	Return the time of the Pico RTC
@date	Pico RTC Date	@date or @DATE	Return the date of the Pico RTC
@beep	Beep	@beep or @BEEP	Make "beep" on integrated buzzer

@redon	RED LED ON	@red on or @RED ON	Make RED LED ON
@redoff	RED LED OFF	@red off or @RED OFF	Make RED LED OFF
@blueon	BLUE LED ON	@blue on or @BLUE ON	Make BLUE LED ON
@blueoff	BLUE LED OFF	@blue off or @BLUE OFF	Make BLUE LED OFF

Figure 13 TCC @commands set